


How to update the Hi Face Two with DFU


This document describes how to update the firmware on the Hi Face Two device with the DFU.

1. Unzip the file "*hiFaceTwo_Update_r0x.xx.zip*"
2. Open the folder "*hiFaceTwo_Update_r0x.xx*"




3. Start the program: **MUSBAudioDfu.exe**


Below the Screenshot shows the main windows of MSUBAudioDfu.exe



4. Now you can connect the HiFace Two to the USB port and the MSUBAudioDfu will show the Fw revision and the Product:



5. Click on "Start" button and when the update is finished check the firmware revision.



6. Now the unit was updated.

NOTE: If the unit will be not recognized then contact M2tech Technical Support.